

GUARDALL SAFE AND LOCK

TEL. 1300 1 SAFES (1300 1 72337)

IT4000 OPERATING INSTRUCTION

1. TO OPEN AND CLOSE

- a. Press “ * “ as start key always**
- b. Enter combination code (4 – 8 Digits. Factory setting 0000)**
- c. Press “ # “ to confirm**
EG – * – “ 0, 0, 0, 0, 0, 0 ” – #
- d. Green LED flashes & a series of beeps follows, accepting the code as correct**
- e. When the incorrect code has been entered, the red LED flashes 3 times along with 3 long beeps**
- f. If the incorrect code has been entered 4 times, the keypad will shutdown(lock out) for 5 minutes. After the 5 minutes has passed the keypad will come back to life.**

2. TO CHANGE COMBINATION CODE

ALWAYS CHANGE COMBINATION WITH DOOR OPEN

- a. Press “# “ Button**
- b. Enter current combination code**
- c. Press “# “ Button**
- d. Enter New Combination Code**
- e. Press “# “ Button**

EG – “# “ – 0, 0, 0, 0, 0, 0 – “ # “ – 1, 2, 3, 4, 5, 6 – “ # “

3. TO CHANGE BATTERIES WHEN LOW

Rotate keypad in an anti-clockwise direction to unclip and hold in your hand. This will reveal 4 x AAA size batteries. Replace all 4 at one time using alkaline batteries. Turn and clip keypad back on and it will resort to normal function.

Note: Always have safe door in the open position when following the code changing procedure. Always double check the new code has entered correctly before locking the safe door.