

GUARDALL SAFE & LOCK

www.guardall.com.au

Digital Lock Instructions

WRONG TRY PENALTY

- Three (3) consecutive invalid codes initiates five minute delay period.

LOW BATTERY WARNING

- LOW BATTERY will appear in the LED readout. Safe will not open.

AUDIO SIGNAL

- Audible CLICK indicates code entry is valid or accepted.
- Triple signal indicates code is invalid or not accepted.

OPENING THE LOCK (factory set to *4560#)

- 1). Enter the valid FOUR (4) digit code. Start with * and end with #.
- 2). The lock will indicate a valid code entry with an audible CLICK.
- 3). Within four (4) seconds, turn handle to the open position.
- 4). Pull door open.
- 5). Invalid code entry – Lock will signal three (3) times.

CHANGING MASTER CODE

ALWAYS PERFORM THIS OPERATION WITH THE DOOR OPEN

- 1). Open the door and press the “M” button.
- 2). Enter new code (four Digits) and press #, test code before closing the safe

CHANGING YOUR BATTERIES

- 1). Slide the battery cover on the right hand side of fascia off and
Replace with four (4) alkaline “AA” cells, carefully replace cover

We recommend that your safe is serviced at regular intervals, 12 – 18 months would be the optimum period if the safe is used daily. Failure to service your safe may eventuate in an expensive breakdown, to avoid this please have your safe checked.

To have your safe serviced, please contact your supplier to arrange a time to suit you.